

C DEELOW DANEL MOLINITING SECLIDE ASSEMBLY LISING	
R BELOW PANEL MOUNTING, SECURE ASSEMBLY USING -40 x .38 MIN. TO .44 MAX. LONG SCREWS OR READED STUDS AND HEX NUTS (X4) OR THE METRIC QUIVALENT. THIS MAY REQUIRE REMOVING THE 3 SCREWS ARKED 'A'. IF SO, CHECK IF A COPPER SHIM OR SHIMS THE BETWEEN THE COLLAR AND HOUSING, THEY MUST BE PLACED BEFORE REATTACHING THE HOUSING. BE CAREFUL OT TO DAMAGE ENCODER DISCS. SCREWS MARKED 'A' ARE BE HAND TIGHTENED AND SECURED WITH A "LOCTITE" COUVALENT THREAD BONDING AGENT.	
CTI <u>ELECTRONICS CORPORATION</u> WWW.CTIELECTRONICS.COM	<u> </u>
NEMA12 (IP54) OEM NDUSTRIAL TRACKBALL 2.0" DIAMETER T1XXX MODEL	
61644-1	REV. D DRAWN BY
ROVED DATE 10-08-13	PSB