
















# MINI TRIM BUTTON STYLES

## T1, T4, T5 AND T8 MINI TRIM BUTTON STYLES

|   |  |   |
|---|--|---|
| <p><b>A - 2-WAY JOG</b></p>    | <p><b>B - TALL JOG</b></p>              | <p><b>C - ROCKER</b></p>             |
| <p><b>D - CONE</b></p>         | <p><b>E - LRUD HAT</b></p>              | <p><b>F - IOUD HAT</b></p>           |
| <p><b>G - HAT</b></p>        | <p><b>H - STADIUM</b></p>             | <p><b>J - CASTLE</b></p>           |
| <p><b>K - 4-WAY JOG</b></p>  | <p><b>L - SHORT BAT</b></p>           | <p><b>M - LONG BAT</b></p>         |
| <p><b>N - POST</b></p>       | <p><b>P - 4-40 THREADED POST</b></p>  | <p><b>Q - ROTATED STADIUM</b></p>  |